

ASSEMBLY AND INSTRUCTION MANUAL MODEL **OD**1520 LAGOON

© 2020 KURT BEIER & KATI QUINGER



For general informations please refer to the information about outdoor furniture! Bullfrog recommends the suitable waterproofed protective covers for outdoor furnitures.



Braided back, available in "nature" or "black"



Practical throw pillow for individual comfort



A practical stool adapted to the sofa

FUNKI - How ist works:



1. Take the cushion at its upper side and put the cushion on your knees with the zipper on the bottom. The seamless side faces you.



2. Move the upper part of the cushion towards yourself until the final position is reached.



3. Now you are able to move the upper part backwards until the upper part of the cushion will click into place in the zero position.



4. Now put the cushion in the preferred position (e.g. in the back, seamless side in front and zipper at the bottom). By pulling the upper part of the chushion towards yourself, you are now able to choose among 16 raster positions, however you like it.

© 2020 KURT BEIER & KATI QUINGER

Safety note:

ATTENTION!

In order to prevent damage, don't move or lift the furniture at braid or back. In case of transport, it is absolutely necessary to lift up the furniture from below.



Keep all documents relating to the purchase of your furniture carefully, even beyond the legal warranty period of 2 years. You will find all important information in your product folder and also on our website www.bullfrog-design.com

Disassembly, transport protection:

Info:

ATTENTION! To ensure secure assembly, please observe the individual steps of instruction!

The furniture should always be mounted in pairs (2 persons)!

1. Position the elements at the place supposed to stay and remove the foil and the cardboard.





- 2. Tilt the element forwards. Use a suitable support to avoid damage to the cover or your floor.
- 3. Unscrew the 4 screws (h) from the transport protection (E). Remove the transport protection (E) by lifting the element slightly and pulling the transport protection (E) away to the side.



4. Place the element back on its feet.