

PRODUCT INFORMATION

0001 FUNKI

© 2009 KURT BEIER & KATI QUINGER













*Bullfrog offers a wide range of cushions. With any model we recommend consistent cushions.
If you desire further cushions for an individual interior design, we will gladly advise you.*



FUNKI: A MULTIFUNCTIONAL CUSHION WITH FLEXIBLE HIGH BACK COMFORT FOR AN INDIVIDUAL SITTING QUALITY. WITH ITS LOOK AND SOFTNESS OF A CUSHION IT IS THE IDEAL SUPPLEMENT FOR EVERY SOFA WITH A LOW BACK. TRY IT AND TAKE A COMFORTABLE SEAT WITH FUNKI! UNIQUE PIECE PRODUCTION.




Processing options of main seam / decorative seam

	Plain seam	Lap seam	Raw edged	Moccasin seam extra charge	Twin seam extra charge	KR* (zipper piping) extra charge	Overcast seam	Piping	Two needle seam	Square seam extra charge
										
Fabric	x						x			
Leather	x									
Fur										
Fake fur	x									


It is possible to order main seam or decorative seam either tone in tone like the colours of cover or in the contrasting colours white, nature, grey, rust and black. On request special colours possible.

*Zipper piping: optionally in the colours black, red, nature or light grey.


05.04.2023



Funki S
Functional cushion
(tapered cushion)
(plain seam)
62 x 78
582



Funki L
Functional cushion
(tapered cushion)
(plain seam)
90 x 78
583




Funki S
Functional cushion
(tapered cushion)
(leather: raw edged)
(fabric: decorative overcast seam)
62 x 78
589




Funki
Functional cushion
(with dart)
(plain seam)
62 x 78
586

Each cushion is handmade and unique. Deviations to the listed measurements may occur. Possible causes are different cover materials (fabric, leather) and different versions of seams.


FUNKI - how it works:




1. Take the cushion at its upper side and put the cushion on your knees with the zipper on the bottom. The seamless side faces you.



2. Move the upper part of the cushion towards yourself until the final position is reached.



3. Now you are able to move the upper part backwards until the upper part of the cushion will click into place in the zero position.



4. Now put the cushion in the preferred position (e.g. in the back, seamless side in front and zipper at the bottom). By pulling the upper part of the cushion towards yourself, you are now able to choose among 16 raster positions, however you like it.